

Flip-it! 400

Instructions and Suggestions



Folds back flat for storage on your flash or in your pocket or purse.
Stretch the strap over the front of your flash, lining it up with the flash.
Fold back when not in use.

Flip-it 400 is designed to greatly increase the lighting quality from your Nikon SB400 flash for horizontal photographs in rooms with normal white ceilings. Red-eye problems are decreased, skin tones are smoother and shadows are softer. Always use the 90 degree up flash position.

Because it allows you to bounce the light off the ceiling and the Flip-it simultaneously, you get two light sources from one flash. By changing the angle of the reflector on the hinge, you may control the power of the two light sources with respect to each other. Just a little experimentation will allow you get the light that pleases you the most in each photo situation.

For outdoor photos of close subjects, try using your Flip-it 400 for more natural fill lighting in back-lit situations.

The reflector is adjustable for softness and power. For close-up portraits and candid, try the reflector tipped slightly back toward yourself, so the flash barely skims the surface. As you tip the reflector forward in very small amounts, the amount of front lighting increases with respect to the top lighting off the ceiling.



More questions: email info@dembflashproducts.com